

- A) ALL WATER PIPING MATERIAL BEFORE WATER METER MUST BE TYPE K COPPER OR BRASS.
- B) ALL WATER PIPING MATERIAL BETWEEN WATER METER AND APPROVED BACKFLOW PREVENTER MUST BE LISTED AS APPROVED IN THE STATE PLUMBING CODE.
- C) NO DRAIN TEE OR ADDITIONAL STOPS ARE ALLOWED BETWEEN PROPERTY LINE AND WATER METER. EVERY FALL, THE PROPERTY OWNER MUST CALL SPRWS FOR WATER SHUT OFF AND WATER METER REMOVAL. WATER TRAPPED IN RISER CAN BE BLOWN OUT AFTER SPRWS SHUTS OFF WATER IN STREET AND REMOVES WATER METER.
- D) WATER PIPING FOR WATER METER SETTING AND APPROVED BACKFLOW PREVENTER MUST BE LOCATED IN AN APPROVED LOCKABLE ABOVE GROUND ENCLOSURE THAT PROVIDES ACCESS TO ALL PIPEWORK.
- E) A LICENSED PLUMBER MUST INSTALL ALL WATER PIPING FROM PROPERTY LINE THRU APPROVED BACKFLOW PREVENTER. SPRWS PERMITS AND INSPECTIONS ARE NECESSARY.

DR. V.B. 8/7/02	SAINT PAUL REGIONAL WATER SERVICES	SCALE: NONE
CH. T. J.	ST. PAUL, MINNESOTA	
APPROVED:	TYPICAL SEASONAL	REVISIONS: 06/08/16 BM
D. D. W. 8/20/02	2" AND SMALLER	
	LAWN SPRINKLER SERVICE	
		A1-7178